

Support both sides of the page until Doxie starts feeding automatically.













Scan in any order — you'll organize later when you download your scans.



To scan the back of a page, just flip it over and insert it again.



To scan a stubborn page, rotate your document and insert the bottom of the document first.

Some things not to scan:



no staples or paper clips



no correction fluid



no crayor



no glitter